



No specific power-up sequence is required, but all power supplies should be active and stable within 500 ms of each other.

